

# DCN-DIS Discussion Unit (Chairman)



**Legend**

- Listening
- Speaking
- Miscellaneous

Volume control

Channel selector

On: Microphone active

Voice mode




Loudspeaker

Voting buttons

Priority button

Microphone button

On: Chairman present



## Microphone

### To enable the microphone:

Push the microphone button to enable the microphone of your discussion unit. When the red light around the microphone button comes on, you can speak.

### To disable the microphone:

When the red light around the microphone button is on, push the microphone button to disable the microphone. The red light around the microphone button goes off.

## Priority function

With the priority button, you can temporarily disable the microphones of all delegates. At the same time, the priority button enables your own microphone. The system has the possibility to:

- Play a chime when you push the priority button.
- Erase the request-to-speak list and the speakers list when you push the priority button.

When you release the priority button, the system disables your microphone. When the speakers list is not erased, the system enables the microphones of the speakers again.

## Voice mode

When your discussion unit is in the Voice mode, the microphone is always enabled. Push and hold the microphone button to temporarily disable the microphone.

## Channel selector



### Note

Some types of discussion units do not have a channel selector. With these types of discussion units, you cannot change the audio signal that is sent to the headphones.

With the channel selector, you can select the channel that is sent to the headphones. The channel selector is automatically enabled when you connect headphones to the discussion unit.

## Voting



### Note

Some types of discussion units do not have voting buttons. With these types of discussion units, you cannot make votes.

Standard procedure:

- 1 The chairman or operator starts a voting session. When the voting session is started, the yellow light adjacent to voting button 1 flashes.
- 2 Make your vote. You can change your vote until the chairman or operator stops the voting session.

# DCN-DIS Discussion Unit (Single Delegate)



**Legend**

- Listening
- Speaking
- Miscellaneous

Volume control

Channel selector

**On:** Microphone active  
**Flashing:** Last minute

**On:** Request-to-speak  
**Flashing:** First in list

**Voice mode**




Loudspeaker

Voting buttons

Microphone button

**On:** Delegate present



## Microphone

### To enable the microphone:

Push the microphone button to enable the microphone of your discussion unit.

- If the red light around the microphone button comes on, you can speak.
- If the green light around the microphone button comes on, your request-to-speak is accepted. You cannot speak until the red light around the microphone button comes on.

### To cancel a request-to-speak:

When the green light around the microphone button is on, push the microphone button to cancel the request-to-speak. The operator can disable the possibility to cancel the request-to-speak.

### To disable the microphone:

When the red light around the microphone button is on, push the microphone button to disable the microphone. The red light around the microphone button goes off. The operator can disable the possibility to disable the microphone.

### To make a request-to-respond:



#### Note

Some types of discussion units do not have voting buttons. With these types of discussion units, you cannot make a request-to-respond.

When the operator enables the response function, you can make a request-to-respond to speak to the current speaker. Push voting button 3 to make a request-to-respond. The yellow light around voting button 3 flashes. You cannot speak until the operator adds you to the response list. When the operator adds you to the response list, the red light around the microphone button comes on.

### To cancel a request-to-respond:

When the yellow light around voting button 3 flashes, push voting button 3 to cancel the request-to-respond. The operator can disable the possibility to disable the request-to-respond.

## VIP mode

When the yellow light around the microphone button comes on, your discussion unit is in the VIP mode. In the VIP mode:


- You can always enable the microphone.
- You cannot make a request-to-speak.

## Voice mode

When your discussion unit is in the Voice mode, the microphone is always enabled. Push and hold the microphone button to temporarily disable the microphone. In the Voice mode, you cannot make a request-to-speak.

## Auxiliary control

Your discussion unit can have two microphone buttons (refer to the figure below).



When your discussion unit has two microphone buttons, the left microphone button is an auxiliary control.

## Channel selector



#### Note

Some types of discussion units do not have a channel selector. With these types of discussion units, you cannot change the audio signal that is sent to the headphones.

With the channel selector, you can select the channel that is sent to the headphones. The channel selector is automatically enabled when you connect headphones to the discussion unit.

## Voting






#### Note

Some types of discussion units do not have voting buttons. With these types of discussion units, you cannot make votes.

Standard procedure:

- 1 The chairman or operator starts a voting session. When the voting session is started, the yellow light adjacent to voting button 1 flashes.
- 2 Push voting button 1 to show the system that you are present. The yellow lights around the available voting buttons flash.
- 3 Make your vote. You can change your vote until the chairman or operator stops the voting session.

# DCN-DIS Discussion Unit (Dual Delegate)



## Microphone

### To enable the microphone:

Push your microphone button to enable the microphone of the discussion unit.

- If the red light around your microphone button comes on, you can speak.
- If the green light around your microphone button comes on, your request-to-speak is accepted. You cannot speak until the red light around your microphone button comes on.

### To cancel a request-to-speak:

When the green light around your microphone button is on, push your microphone button to cancel your request-to-speak. The operator can disable the possibility to cancel the request-to-speak.

### To disable the microphone:

When the red light around your microphone button is on, push your microphone button to disable the microphone. The red light around your microphone button goes off. The operator can disable the possibility to disable the microphone.

## VIP mode

When the yellow light around your microphone button comes on, the discussion unit is in the VIP mode. In the VIP mode:

- You can always enable the microphone.
- You cannot make a request-to-speak.

## Voice mode

When the discussion unit is in the Voice mode, the microphone is always enabled. Push and hold your microphone button to temporarily disable the microphone. In the Voice mode, you cannot make a request-to-speak.

## Channel selector



### Note

Some types of discussion units do not have a channel selector. With these types of discussion units, you cannot change the audio signal that is sent to your headphones.

With your channel selector, you can select the channel that is sent to your headphones. Your channel selector is automatically enabled when you connect your headphones to the discussion unit.